

AC6815 Capsule Slip Ring Assembly

Proper Use and Mounting Instructions

Shaft mounted units:

1. Position the slip ring in the desired location and equally tighten both set screws (6-32 x .50 supplied) to the shaft on each end of the unit. Maximum torque 25 lb-in. (*DO NOT OVER TORQUE*)
2. Route the wiring and make the necessary connections. Do not allow the wiring to restrict free rotation of the slip ring.

3. (NOT SUPPLIED) in the anti-rotation tab to the 2.45" dimension as shown.

Flange mounted units:

1. (NOT SUPPLIED) in the anti-rotation tab to the 2.45" dimension as shown.

CAUTION:

Because of possible geometric mismatching between the customer's application and the slip ring, "hard