DB / DBE Matrix™ Series Motors

Proper Mounting Instructions

Many of the motor and alternator products of ered by Moog are unhoused or frameles b o	the housing comp
prevent them from moving on their respective housing parts and align them to the recommended mounting di 4. When available, there may be features on the motor components that allow for some kind of mechanical section bolt holes or keyways.	
Assembly Precautions	
1. Alnico permanent magnet feld assemblies come with a magnetic ring attached to their side. This ring is known whose purpose is to provide a closed magnetic path until the armature is installed within the feld assembly. It removed or partially slid of of the feld assembly prior to the armature being in place, it springs nor damage to	f this ring is
3. Many motor models will be shipped with the two motor components nested inside one another which is a con user during motor mounting. To protect these components from hitting each other during shipping, a Mylar® s into the air gap that separates these motor parts. This Mylar strip must be removed once the components having installed.	strip is inserted
4. When requested, frameless motor components will be shipped separately. If this is the case and because of magnetic forces developed by rare earth magnet feld assemblies, caution must be taken to prevent the feld striking the armature striking	
Mylar® is a registered trademark of DuPont Teijin Films Specifications and information are subject to change without prior notice.	